



# Eagle and Revolution Hookup Diagrams

## Three Phase WYE




Set circuit type to "wye"

## Three Phase Delta




Set circuit type to "3 wire delta"

## Open Delta




Set circuit type to "3 wire delta"

## Four Wire Delta




Set circuit type to "4 wire delta"

## Two Element Delta




Set circuit type to "3 wire delta"

## 2½ Element WYE



Set circuit type to "2.5 el. wye"

## 2 Wire Single Phase




All Other Channels Optional

Set circuit type to "wye"

## Notes:

- Directional arrows on CTs should point TOWARDS the load.
- The banana jacks are color-coded by channel: Black – Ch1, Red – Ch2, Blue – Ch3, Yellow – Ch4, White – Common. (Not all channels may apply, depending on your model.)
- Do not exceed 600 volts RMS channel-to-channel or channel-to-common.
- Disable unused channels in software for more recording time.
- Phase-to-Phase voltages are measured in 3-wire delta hookups.
- Line-to-neutral voltages are measured in wye hookups.

## 3 Wire Single Phase



All Other Channels Optional

Set circuit type to "wye"